7/16/13 Sonifex SCi FAQ

FAQs

Sonifex SCi Frequently Asked Questions (FAQ)

This FAQ (frequently asked questions) answers some of the popular questions asked about the Sonifex SCi software. If you have any specific questions regarding the operation of SCi which aren't covered below, please contact your nearest distributor, or Sonifex directly.

How to install SCi onto a computer using Windows 7?

Run the Installation CD.

Click on Sci 2 (Full Installation).

From the pop up box Opening Setup.exe click "Save File" (The file will "Download" to your pc).

Navigate to the "Downloaded" file, this is usually downloaded to the "Downloads" Folder unless changed by the user.

Right click on the downloaded file setup.exe and select "Run as Administrator" from the pop up window.

Once installed run as normal and the units should now be discovered, if not contact technical support for further advice: technical.support@sonifex.co.uk

Sonifex Ltd. 61 Station Road, Irthlingborough, Northants, NN9 5QE, UK. Tel: +44 (0)1933 650700 Fax: +44 (0)1933 650726 EMail: sales@sonifex.co.uk